Telephone:

Fax:

VAT Registration No.:

Name: Manufacturer: Ford

Address: Model:

Year:

Registration:

Tel - Private: Mileage: Tel - Business: Job number:

Tel - Mobile Date

31	Battery -		
30	Battery +		
S84	Boot lid/tailgate release switch		
A31	Central locking control module		
M58	Central locking motor, boot lid/tailgate		
M46	Central locking motor, driver		
M47	Central locking motor, left rear		
M48	Central locking motor, passenger		
M49	Central locking motor, right rear		
A94	Combination control module/relay		
X1	Data link connector (DLC)		
S226	Door contact switch, driver		
S227	Door contact switch, left rear		
S228	Door contact switch, passenger		
S229	Door contact switch, right rear		
EP2	Earth point location 2		
EP3	Earth point location 3		
EP6	Earth point location 6		
EP9	Earth point location 9		
F	Fuse		
S27	Hazard warning lamps switch		
15	Ignition switch - ignition ON		
A5	Instrument panel		

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

 Manufacturer: Ford
 Model: Focus ('98) 1,4
 © Autodata Limited 2007

 Engine code: FXDA/C
 Output: 55 (75) 5000
 10.03.2007

 Tuned for: R-Cat
 Year: 1998-05
 V6.410 //Autodata

