

Telephone:
Fax:
VAT Registration No.:

Name:
Address:

Tel - Private:
Tel - Business:
Tel - Mobile

Manufacturer: Ford
Model:
Year:
Registration:
Mileage:
Job number:
Date

S354	Alarm system boot lid/tailgate inhibit switch
31	Battery -
30	Battery +
S23	Bonnet switch
S84	Boot lid/tailgate release switch
A31	Central locking control module
M58	Central locking motor, boot lid/tailgate
M46	Central locking motor, driver
M47	Central locking motor, left rear
M48	Central locking motor, passenger
A94	Combination control module/relay
X1	Data link connector (DLC)
S226	Door contact switch, driver
S227	Door contact switch, left rear
S228	Door contact switch, passenger
S229	Door contact switch, right rear
EP2	Earth point location 2
EP3	Earth point location 3
EP6	Earth point location 6
EP7	Earth point location 7
EP9	Earth point location 9
F	Fuse
S27	Hazard warning lamps switch
15	Ignition switch - ignition ON
A5	Instrument panel

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

